



ASSEMBLY INSTRUCTION

TL8807


1




2



3



Complete



PART LIST

1	2	3
x1	x1	x1
4	5	S1
x1	x1	x8

ADULT ASSEMBLE